



單乙閥濾水清洗步驟


(0) A. 過濾



(1) B. 逆洗 (3-10分)



(2) E. 排清 (1-5分)



【濾水清洗步驟】

(0) A. 過濾 →

(1) 關閉出水口 →

B. 逆洗(3-10分鐘) →

(2) E. 排清(1-5分)

平時轉至過濾位置，如遇壓力錶壓力比平常較高 $0.5\sim 1\text{kg}/\text{cm}^2$ ，則操作清洗步驟一次(但至少每二個月務必操作一次，預防濾材硬化)



1A0001A